

NOTES:

- 1. USE 1" POLYETHYLENE CTS
- 2. CONTRACTOR WILL PROVIDE ALL MATERIAL AND INSTALL SERVICES UNDER DCWS SUPERVISION.
- 3. ALL TAPS WILL BE MADE IN ACCORDANCE WITH DCWS STANDARDS AND AWWA GUIDELINES FOR TAPPING THROUGH POLYETHYLENE ENCASEMENT.

##